




### Jib Arm Crane Exploded

1. Weight T-Bar
2. Yoke
3. Axle x 2
- 4a. Long Boom Knob
- 4b. Short Boom Knob
5. Jib Arm Outer Boom
6. Jib Arm Inner Boom
7. Camera Plate
8. Tilt Plate Knob
9. Tilt Plate Shoe
10. Jib Arm Inner Lower Bar
11. Lever Knob x 2
12. Jib Arm Outer Lower Bar
13. Wt Cage "T" Bar Knob
14. Tripod Base Plate
15. Safety Nut and Washer
16. Speed Nut
17. Jib Adapter Plate
18. Star Knob x 2
19. Weight Clip x 2
20. Camera Plate Knob





**3D JIB ARM CRANE EXPLODED**



### Jib Arm Crane

For Part Listings and Part Numbers, Please Refer to the Diagram "JIB ARM CRANE EXPLODED"



\*NOTE: For maximum safety, telescope the Jib only to the shortest length necessary to achieve the desired shot.



**Jib Truss Kit -  
No Extension**

Parts List


- 1. Dog
- 2. Eyebolt x 2
- 3. Tower Support
- 4. Top-θ Extension Cable





### Jib Truss Kit - 1 Extension

#### Parts List

1. Eyebolt x 2
2. Top 2 Extension Cable
3. Wing Support x 2
4. Tower Support
5. Turnbuckle x 2
6. Wing 2 Extension Cable
7. Jib
8. 1 Extension
9. Mushroom



3D JIB TRUSS KIT SINGLE EXTENSION



### Video Assist Arm

#### Parts List

1. 8" Monitor Bracket
2. Adjustment Knob x 2
3. 1/4 20 Ball x 2
4. Swivel Ball Bracket x 2