


In the Box



Gimbal
× 1



BG30 Grip
× 1



USB-C Charging Cable
(40 cm)
× 1



Lens-Fastening Strap
× 1



Extended Grip/Tripod
(Metal)
× 1



Quick-Release Plate
(Arca-Swiss/Manfrotto)
× 1



Briefcase Handle
× 1



Camera Riser
× 1



Carrying Case
× 1




Multi-Camera Control
Cable (USB-C, 30 cm)
× 1



Multi-Camera Control
Cable (Sony Multi, 30
cm)
× 1



Multi-Camera Control
Cable (Micro-USB, 30
cm)
× 1



Multi-Camera Control
Cable (Mini-USB, 30
cm)
× 1



Hook-and-Loop Strap
× 3



D-Ring Camera
Mounting Screw
1/4"-20
× 2



RSA/NATO Port Cover
× 1



Pan Axis Sleeve
× 1



Screw 1/4"-20
× 1



Phone Holder
× 1



Focus Motor
× 1



Focus Motor Rod
Mount Kit
× 1



Focus Gear Strip
× 1



Image Transmitter
× 1



Cold Shoe to 1/4"-20
Adapter
× 1



USB-C Power Cable (20
cm)
× 1



Mini-HDMI to HDMI
Cable (20 cm)
× 1



Mini-HDMI to Mini-
HDMI Cable (20 cm)
× 1



Mini-HDMI to Micro-
HDMI Cable (20 cm)
× 1



M4 Screw (10 mm)
× 6



Allen Wrench (3 mm)
× 1